

# FM9, FM18, FM36 Replacement Battery Charger

## Instruction Manual Changes

### Section 3-9. Charging the Battery Pack

#### 2 The Battery Charger

Depending on your country and availability, the FM9, FM18, FM36 replacement battery charger will be supplied in one of two formats :

If the unit supplied is an Adapter 6201, Type FW1299 then the input voltage and pins will be supplied to match your country. Follow the charging instructions given in the main section of the manual, page 3-9 (3), or in any later addendum that you have.

If the unit supplied is an adapter Type FM7650/18 then the charger will be supplied with worldwide pin adapters (UK, Euro, USA, Japan, Australia) and will operate with a input of 100V-240V, 47-63 Hz. The FM9, FM18, FM36 requires a constant current of about 70mA for charging. The 18V adapter has a voltage dropping resistor fitted in the connector so that it provides the required current to the battery pack. You should only use *this* charger with the FM9, FM18, FM36 and not an 18V substitute since this will not have the required dropping resistor fitted to regulate the current. Again follow the charging instructions given in the main section of the manual, page 3-9 (3), or in any later addendum that you have.