

# CONTENTS

---

<b>SECTION 1</b>	<b>INTRODUCTION</b>	<b>1-1</b>
	1-1 About the Instruction Manual	1-1
	1-2 Introducing the RM4 Resistance Meter Family	1-1
	1-3 Construction and Accessories	1-2
	1-4 Specifications	1-3
<b>SECTION 2</b>	<b>ASSEMBLY INSTRUCTIONS</b>	<b>2-1</b>
	2-1 Unpacking	2-1
	2-2 Physical layout of the RM4	2-1
	2-3 Assembling the RM4 and Probe Arrays for Field Use	2-2
	1 PA1 Twin Electrode Probe Array	2-2
	2 PA3 Four Probe Array	2-5
	2-4 Assembling the RM4 and PA5 Array for Field Use	2-7
	1 Early Versions of the PA5	2-7
	2 Assembly	2-7
	3 AD1 Adapter - Twin Array	2-11
	4 AD2 Adapter - Gradient Array	2-11
	5 AD3 Adapter - Wenner, Double-Dipole, Schlumb.	2-12
	6 AD4 Adapter - Pole-Pole Array	2-12
<b>SECTION 3</b>	<b>BATTERIES AND CHARGING</b>	<b>3-1</b>
	3-1 Battery Types	3-1
	1 Rechargeable Ni-Cad batteries	3-1
	2 Primary Batteries	3-1
	3-2 Battery Installation and Replacement	3-2
	3-3 Charging the battery pack	3-3
	1 Battery Low Warning	3-3
	2 The Battery Charger	3-3
	3 Charging Instructions	3-4
<b>SECTION 4</b>	<b>OPERATING INSTRUCTIONS</b>	<b>4-1</b>
	4-1 Introduction	4-1
	4-2 Switching on for the First Time	4-1
	4-3 LCD Display	4-2
	1 High Contact Resistance	4-2
	2 Contact Resistance Indicator	4-2
	3 Battery Low Indicator	4-3
	4 Over-Range Indicator	4-3
	5 Negative Readings	4-3
	4-4 Filter Switch	4-3
	4-5 High Contact Resistance Mode	4-4

4-6	Use of the Analogue Output	4-5
4-7	Care of the Instrument and Accessories	4-5
<b>SECTION 5</b>	<b>FIELD PROCEDURE</b>	<b>5-1</b>
5-1	Introduction	5-1
5-2	Safety Precautions	5-1
5-3	Planning a Survey	5-2
1	Area or Line Survey	5-2
2	Traverse Pattern	5-3
3	Grid Size	5-3
4	Sample and Traverse Interval	5-3
5	Changing Grid Size, Sample and Traverse Interval	5-5
5-4	Use of Survey Guide Lines	5-5
5-5	Use of Measurement Tapes	5-8
5-6	Area Surveying with a 0.5m Twin Array (PA1 + PA5)	5-9
1	Introduction	5-9
2	Positioning the Remote Probes	5-9
3	Remote Probe Separation	5-9
4	Remote Probe Insertion Depth	5-10
5	Repositioning the Remote Probes	5-10
6	Positioning the Mobile Probes	5-10
7	Mobile Probe Insertion Depth	5-11
8	Instrument Settings	5-11
9	Survey Procedure	5-12
5-7	Area Surveying with 0.25m to 2m Twin Arrays (PA5)	5-13
1	Introduction	5-13
2	Positioning the Remote Probes	5-13
3	Instrument Settings	5-13
5-8	Area Surveying, Wenner, Double-Dipole Arrays (PA5)	5-14
1	Introduction	5-14
2	Positioning the PA5 Probes	5-14
3	Probe Insertion depth	5-14
4	Instrument Settings	5-15
5	Survey Procedure	5-15
5-9	Area Surveying, Wenner, Double-Dipole Arrays (PA3)	5-17
1	Introduction	5-17
2	Probe and Cable Separation	5-18
3	Probe Positioning	5-18
4	Probe Insertion depth	5-18
5	Instrument Settings	5-18
6	Survey Procedure	5-19
5-10	Dealing with Obstacles	5-20
5-11	Doing a Line Survey	5-20
5-12	Avoiding Split Surveys	5-20
<b>SECTION 6</b>	<b>TWIN SURVEY INTERPRETATION</b>	<b>6-1</b>
6-1	Introduction	6-1
6-2	Background Resistance	6-2
6-3	Response to Archaeological Structures	6-2
1	Introduction	6-2
2	Response Polarity	6-2
3	Response Width and Form	6-4
4	Response Strength and Variation with Depth	6-4

5	Response Contrast, Geology and Season	6-5
6	Response Complexity	6-5
6-4	Unwanted Response to other Structures and Influences	6-6
6-5	Conversion to Resistivity	6-6
6-6	Further Information	6-6

---

<b>APPENDIX A</b>	<b>CURRENT / POTENTIAL TERMINALS</b>	<b>A-1</b>
<b>APPENDIX B</b>	<b>CHARGER, ANALOGUE, RANGE</b>	<b>B-1</b>
	B-1 Introduction	B-1
	B-2 Pin Connections	B-1
	B-3 Range Status Outputs	B-2
<b>APPENDIX C</b>	<b>MAKING YOUR OWN TWIN ARRAY</b>	<b>C-1</b>
	C-1 Introduction	C-1
	C-2 Mobile Frame	C-1
	C-3 Remote Probes	C-3
	C-4 Connecting Cable	C-3
	C-5 Twin Array Wiring	C-3
<b>APPENDIX F</b>	<b>SURVEY AIDS</b>	<b>F-1</b>
	F-1 Grid Diagonal Dimensions	F-1
	F-2 Survey Guide Line Colour Coding	F-1
	F-3 Survey Sheets	F-2
<b>APPENDIX G</b>	<b>SEALED CONNECTORS</b>	<b>G-1</b>
<b>APPENDIX H</b>	<b>CONVERSION TO RESISTIVITY</b>	<b>H-1</b>
	H-1 Introduction	H-1
	H-2 Conversion to Resistivity	H-1
	H-3 Remote Probe Contact Resistance	H-2
<b>APPENDIX I</b>	<b>FURTHER READING</b>	<b>I-1</b>
<b>APPENDIX J</b>	<b>INTERFERENCE</b>	<b>J-1</b>
	J-1 Introduction	J-1
	J-2 Interference whilst Surveying	J-2
	J-3 Interference whilst Dumping Data	J-2
<b>APPENDIX K</b>	<b>EARLY PA5 FRAMES</b>	<b>K-1</b>
	K-1 Introduction	K-1
	K-2 Replacement Tables and Figures	K-1